3B6 Operator Manual

Language Setting

Starting from the main LMI screen, press and release the **Wrench pushbutton**. The display will change to the Language menu.



Press and release the **ENTER pushbutton** the display changes to allow a new selection of the language. Then press and release the LEFT or RIGHT ARROW to move the asterisk over the value to change it.



Press and release the **UP or DOWN pushbutton** to select the proper language number.

To confirm this setting press and release the **ENTER pushbutton**. The asterisk will disappear. Allow 20-30 seconds before cycling power to save the change.

Language/text settings

0 = English/SAE

1 = Spanish

2 = French

3 = English/metric

Press and release the TARE/ESC pushbutton, twice to return to the main LMI screen.